

The Logopost Hand Dibbler
For use in hard or firm ground

Document DJS-TLL-INS-090510-D



Hand Dibbler Instructions

Document DJS-TLL-INS-090510-D

1



(1) Hold the Logopost in one hand and the hand Dibbler in the other, and locate where the first hole will be

2



(2) Push down on the hand Dibbler to form a lead hole

3



(3) At the bottom twist the hand dibbler a few times to widen the hole

4



(4) Pull out the hand Dibbler

5



(5) Push the first leg in to the lead hole until you reach the red depth marker

6



(6) Open the Logopost out and repeat as above for the second leg

7



(7) The hand dibbler can also be used to pull out the Logopost when taking down your barrier

Safety Warning:

When finished with please store the hand dibbler away safely and out of the reach of children.

Please do not use the hand dibbler for anything other than creating a lead ground hole for your Logoposts